








# 1 3/4" ULTIMATE SWINGING FRENCH DOOR TRANSOMS

## 1 FRAME 1 SASH 1/6 HEIGHT (2/0 AND 2/6 HEIGHTS SEE BELOW)

<b>Clad M.O. (mm)</b>	1-8 3/8 (518)	2-1 15/16 (659)	2-7 15/16 (811)	2-9 15/16 (862)	3-1 15/16 (964)	3-7 15/16 (1116)	4-1 1/8 (1248)
<b>Wood M.O. (mm)</b>	1-11 (584)	2-4 9/16 (725)	2-10 9/16 (878)	3-0 9/16 (929)	3-4 9/16 (1030)	3-10 9/16 (1183)	4-3 3/4 (1314)
<b>R.O. (mm)</b>	1-8 7/8 (530)	2-2 7/16 (672)	2-8 7/16 (824)	2-10 7/16 (875)	3-2 7/16 (976)	3-8 7/16 (1129)	4-1 5/8 (1260)
<b>Frame Size (mm)</b>	1-7 7/8 (505)	2-1 7/16 (646)	2-7 7/16 (799)	2-9 7/16 (849)	3-1 7/16 (951)	3-7 7/16 (1103)	4-0 5/8 (1235)
<b>Glass Size (mm)</b>	12 13/16 (325)	14 29/32 (379)	20 29/32 (531)	22 29/32 (582)	26 29/32 (683)	32 29/32 (836)	38 3/32 (968)






1-6 1/4 (464)							
1-8 1/4 (514)	1616	2016	2616	2816	3016	3616	4016
1-6 1/2 (470)	1620	2020	2620	2820	3020	3620	4020
1-6 (457)	1626	2026	2626	2826	3026	3626	4026
10 5/8 (270)							

<b>Clad M.O. (mm)</b>	5-1 1/8 (1553)	5-5 1/8 (1654)	6-1 1/8 (1857)	7-1 1/8 (2162)
<b>Wood M.O. (mm)</b>	5-3 3/4 (1619)	5-7 3/4 (1721)	6-3 3/4 (1924)	7-3 3/4 (2229)
<b>R.O. (mm)</b>	5-1 5/8 (1565)	5-5 5/8 (1667)	6-1 5/8 (1870)	7-1 5/8 (2175)
<b>Frame Size (mm)</b>	5-0 5/8 (1540)	5-4 5/8 (1641)	6-0 5/8 (1845)	7-0 5/8 (2149)
<b>Glass Size (mm)</b>	50 3/32 (1272)	54 3/32 (1374)	62 3/32 (1577)	74 3/32 (1882)

1-6 1/4 (464)				
1-8 1/4 (514)	5016	5416	6016	7016
1-6 1/2 (470)	5020	5420	6020	7020
1-6 (457)	5026	5426	6026	7026
10 5/8 (270)				






## 1 FRAME 2 SASH 1/6 HEIGHT (2/0 AND 2/6 HEIGHTS SEE BELOW)

<b>Clad M.O. (mm)</b>	4-1 1/8 (1248)	5-1 1/8 (1553)	5-5 1/8 (1654)	6-1 1/8 (1857)	7-1 1/8 (2162)
<b>Wood M.O. (mm)</b>	4-3 3/4 (1314)	5-3 3/4 (1619)	5-7 3/4 (1721)	6-3 3/4 (1924)	7-3 3/4 (2229)
<b>R.O. (mm)</b>	4-1 5/8 (1260)	5-1 5/8 (1565)	5-5 5/8 (1667)	6-1 5/8 (1870)	7-1 5/8 (2175)
<b>Frame Size (mm)</b>	4-0 5/8 (1235)	5-0 5/8 (1540)	5-4 5/8 (1641)	6-0 5/8 (1845)	7-0 5/8 (2149)
<b>Glass Size (mm)</b>	14 29/32 (319)	20 29/32 (531)	22 29/32 (582)	26 29/32 (683)	32 29/32 (836)

1-6 1/4 (464)					
1-8 1/4 (514)	4016	5016	5416	6016	7016
1-6 1/2 (470)	4020	5020	5420	6020	7020
1-6 (457)	4026	5026	5426	6026	7026
10 5/8 (270)					

## 1 FRAME 3 SASH 1/6 HEIGHT (2/0 AND 2/6 HEIGHTS SEE BELOW)

<b>Clad M.O. (mm)</b>	6-0 5/16 (1837)	7-6 5/16 (2294)	8-0 5/16 (2446)	9-0 5/16 (2751)	10-6 5/16 (3208)
<b>Wood M.O. (mm)</b>	6-2 15/16 (1903)	7-8 15/16 (2361)	8-2 15/16 (2513)	9-2 15/16 (2818)	10-8 15/16 (3275)
<b>R.O. (mm)</b>	6-0 13/16 (1849)	7-6 13/16 (2307)	8-0 13/16 (2459)	9-0 13/16 (2764)	10-6 13/16 (3221)
<b>Frame Size (mm)</b>	5-11 13/16 (1824)	7-5 13/16 (2281)	7-11 13/16 (2434)	8-11 13/16 (2738)	10-5 13/16 (3196)
<b>Glass Size (mm)</b>	14 29/32 (379)	20 29/32 (531)	22 29/32 (582)	26 29/32 (683)	32 29/32 (836)

1-6 1/4 (464)					
1-8 1/4 (514)	6016	7616	8016	9016	10616
1-6 1/2 (470)	6020	7620	8020	9020	10620
1-6 (457)	6026	7626	8026	9026	10626
10 5/8 (270)					

2/0 AND 2/6 HEIGHTS:		
	2/0 Height	2/6 Height
<b>Clad M.O. (mm)</b>	2-0 1/4 (616)	2-6 1/4 (768)
<b>Wood M.O. (mm)</b>	2-2 1/4 (667)	2-8 1/4 (819)
<b>R.O. (mm)</b>	2-0 1/2 (622)	2-6 1/2 (775)
<b>Frame Size (mm)</b>	2-0 (610)	2-6 (762)
<b>Glass Size (mm)</b>	16 5/8" (422)	22 5/8" (575)

### NOTES:

- Some transoms available factory mullled.
- For stand alone wood units in masonry openings add 11/16" (17) to the masonry opening height only.
- Please contact your local Marvin® representative for information on structural mulling guidelines.
- Please contact your local Marvin representative for masonry openings that include casings and subsills.

Clad Ultimate Inswing French Door Transoms: **CUIFDT**  
 Clad Ultimate Outswing French Door Transoms: **CUOFDT**  
 Wood Ultimate Inswing French Door Transoms: **WUIFDT**  
 Wood Ultimate Outswing French Door Transoms: **WUOFDT**

# 1 3/4" ULTIMATE SWINGING FRENCH DOOR TRANSOMS

1 FRAME 4 SASH 1/6 HEIGHT (2/0 AND 2/6 HEIGHTS SEE BELOW)

<b>Clad M.O. (mm)</b>	7-11 1/2 (2426)	9-11 1/2 (3035)	10-7 1/2 (3239)	11-11 1/2 (3645)	13-11 1/2 (4255)
<b>Wood M.O. (mm)</b>	8-2 1/8 (2492)	10-2 1/8 (3102)	10-10 1/8 (3305)	12-2 1/8 (3712)	14-2 1/8 (4321)
<b>R.O. (mm)</b>	8-0 (2438)	10-0 (3048)	10-8 (3251)	12-0 (3658)	14-0 (4267)
<b>Frame Size (mm)</b>	7-11 (2413)	9-11 (3023)	10-7 (3226)	11-11 (3632)	13-11 (4242)
<b>Glass Size (mm)</b>	14 29/32 (379)	20 29/32 (531)	22 29/32 (582)	26 29/32 (683)	32 29/32 (836)

1-6 1/4 (464)  
 1-8 1/4 (514)  
 1-6 1/2 (470)  
 1-6 (457)  
 10 5/8 (270)



8016  
 8020  
 8026



10016  
 10020  
 10026



10816  
 10820  
 10826



12016  
 12020  
 12026



14016  
 14020  
 14026